

Verigo
Truth in Transit

User Guide


Mobile App

Pods

Cloud

PC Tool

MARCH 2019



USER GUIDE

TABLE OF CONTENTS


GETTING STARTED

| | |
|------------------------------------|---|
| How to download Verigo's App | 3 |
| Creating an account | 4 |
| Signing in | 5 |
| Guest view | 5 |
| Retrieving lost account | 6 |

Using Verigo's App

| | |
|----------------------------|----|
| Nearby: Home Screen | 7 |
| Pod overview | 7 |
| Levels of alert | 8 |
| Selecting a Pod | 8 |
| Pod status | 9 |
| Pod graph | 10 |
| Analysis | 11 |
| Pod settings | 12 |
| Starting a Pod | 13 |
| Session name | 14 |
| Logging details | 15 |
| Alert settings | 15 |
| Advance settings | 16 |
| Selecting your Pods | 16 |
| Confirm settings | 17 |
| Stop logging | 18 |
| Stop Pod | 18 |
| Sharing session data | 19 |
| User Settings | 20 |
| Real-time ping | 20 |
| Offline mode | 21 |
| Offline mode banner | 21 |
| Offline mode screen | 22 |
| Automatic mode | 23 |
| Automatic start | 24 |
| Automatic sync | 26 |
| Automatic stop | 27 |





Verigo's Cloud

| | |
|------------------------------------|----|
| Sessions page | 28 |
| Main menu | 29 |
| Sessions list | 30 |
| Session cell | 31 |
| Session details | 32 |
| Sensor history | 33 |
| Dowloading report | 34 |
| Event history | 35 |
| Administrator | 36 |
| Custom product life profiles | 36 |
| Account settings | 37 |

PC Tool

| | |
|-----------------------------------|----|
| Getting Started | 38 |
| System requirements | 38 |
| Installation | 39 |
| Prerequisite | 41 |
| First-run | 41 |
| Configuring Device Settings | 42 |
| Login | 42 |
| Primary settings | 43 |
| Advanced settings | 43 |
| Scanning nearby Pods | 44 |
| Exporting work log | 46 |
| Sync and stop | 47 |
| Overview | 47 |
| Scan mode | 47 |
| Scan range | 48 |
| Stop options | 48 |
| Scanning nearby loggers | 49 |




GETTING STARTED

HOW TO DOWNLOAD VERIGO'S APP

To interact and view your Pod's logged data, you will need to download the free Verigo app from the Apple App Store® for iOS™ or Google Play Store™ for Android™.

You may also visit Verigo's website on your mobile device to get a direct link to Verigo's app in the App Store or Google Play Store.

1. Navigate to the Apple App Store or Google Play Store on your mobile device
2. In the search bar, enter "Verigo"
3. Download and Install the application.



Go to the App or Play Store and search for "Verigo".

Install the app on your mobile device.

Tap to open Verigo's app.

CREATING AN ACCOUNT

Prior registering an account verify If your company is already registered and contact your administrator about creating you an account within the company. If not, then select the option to register a new company and follow the steps below.


There are two ways to create a Verigo account:

1. From Verigo's app on your mobile device, or
2. Visit Verigo's Cloud site (cloud.verigo.io)


To register a new company account with Verigo using the mobile app, fill out all the required information in the text boxes:

- First name
- Last name
- Valid email address for validation and to retrieve account information.
- Username for logging in to Verigo's Cloud and mobile app
- Password for logging in to Verigo's Cloud and mobile app. Password must have at least eight characters and contain at least one capital letter, one lower case letter, and one number
- Password confirmation
- The name of the company that is registering

After registering you will receive an email confirmation to complete the registration process.



The screenshot shows the 'Sign Up' screen of the Verigo mobile app. At the top, there's a 'Return to app' link and the Verigo logo. Below the header, a message states: 'Please provide the following information to create your account. All fields are required.' The form contains several input fields: 'first name', 'last name', 'e-mail', 'username', 'password', 'confirm password', and 'your company'. Each field has a corresponding icon (e.g., a key for password, an envelope for email). At the bottom, there is a 'REGISTER' button and a link that says 'Already registered? Return to login.'



The screenshot shows the registration page on the Verigo cloud web site. The browser address bar shows 'https://cloud.verigo.io/#/newaccount'. The page features the Verigo logo and the same registration form as the mobile app. The form includes fields for 'first name', 'last name', 'e-mail', 'username', 'password', 'confirm password', and 'your company'. A 'REGISTER' button is at the bottom, with a link below it that says 'Already registered? Return to login.'

You may also register direct on our cloud web site at cloud.verigo.io



Verigo
Truth in Transit

| www.verigo.io


| 352.363.5070

| info@verigo.io

SIGNING IN

To interact with and manage nearby Pods simply enter your account's credentials.


1. Enter your username on the first text box where it says "username".
2. Enter your password in the second text box where it says "password".
3. Tap the "Login" button.



GUEST VIEW

You do not need to have an account to view nearby Pods. If you simply want to see the current reading of the nearby Pods simply select the "Guest View" option on the login screen. "Guest View" allows you to view the nearby pods without having a registered account.

However, you will not be able to start, stop, store, sync, or collect real-time pings in "Guest View" mode.




Tap the "GUEST VIEW" button on the login screen to see nearby Pods.

RETRIEVING LOST ACCOUNT INFORMATION

If you do not remember your username or password, there are two ways to recover and reset your account credentials. You can either recover from the mobile app, or you can visit Verigo's Cloud home page on the web at cloud.verigo.io

If you are using Verigo's app to recover your account information, follow these steps:

1. Tap the Sign-Up button at Verigo's app home screen.
2. Tap the Login link near the bottom of the page.
3. Choose which information that you wish to recover.
 - a. Tap the Forgot your password? link if you are trying to reset your password or;
 - b. Tap the Forgot your username? link if you are trying to recover your username.
4. Enter the email you used to register your account and tap the SUBMIT button.
5. After you submit you will receive an email with further instructions.
6. If you are using an Internet browser to recover your account credentials visit: cloud.verigo.io (Skip steps 1 and 2)



Tap **"Username"** or **"Password"**

A screenshot of the Verigo app's 'Forgot your username?' screen. The Verigo logo is at the top. Below it, the text 'Forgot your username? Enter the email you used to register and we will send you an email with your username.' is displayed. There is a text input field labeled 'email' with a small envelope icon to its right. Below the input field is a grey 'SUBMIT' button. At the bottom, there is a link that says 'Return to login'.

Enter the email associated with your account.

A screenshot of the Verigo app's 'Forgot your username?' screen. The Verigo logo is at the top. Below it, the text 'Forgot your username? Enter the email you used to register and we will send you an email with your username.' is displayed. A green message box contains the text 'An email has been sent to . Please check your email for further instructions login.' Below this is a text input field containing the email 'iguisard@verigo.io' with a small envelope icon to its right. Below the input field is a blue 'SUBMIT' button. At the bottom, there is a link that says 'Return to login'.

Check your email for further instructions.

USING VERIGO APP

NEARBY PODS: HOME SCREEN



After entering your credentials and successfully signing in to your account, you are directed to the **Nearby** Pods tab, the home screen.

This screen shows all the currently active Pods near you up to a range of 40 meters (~120 ft.) *. This screen shows the most basic and vital information about your Pod(s).

POD OVERVIEW

Each individual row is a Pod that is currently active near you. The information displayed is the following:

1. Pod's wireless signal strength.
2. Battery remaining indicator
3. Current name of the Pod
4. Unique unit identification number (MAC address)
5. Indicator of Pod's time active for current session.
6. Real-time temperature (30 second updates)
7. Real-time humidity (Available only on Pod Humidity models).
 - a. Real-time remaining Product Life data (Available only on Pod Quality models)



**The range of 30 meters assumes certain conditions. This could be affected by building materials, other wireless transmitting devices, weather, cosmic rays, sunspot activity, etc.*







LEVELS OF ALERT

The background of the rows in the home screen will sometimes change color due to a Pod having an alert. There are three levels of alert that are shown on the **Nearby** Pods screen:

White background indicates that Pod has no alerts.




Yellow background indicates that a nearby Pod has had its multi-use button recently pressed.


Red background indicates that the Pod has an alert based on thresholds set for the device.

| | | |
|---|--------------------|----------------|
|  | Berry 14 | 24.0°C |
| | 88:C2:55:AF:96:0E | |
|  | Active 1 Day | |
|  | incubator 1 | 25.6°C |
| | 88:C2:55:AF:F7:A4 | |
|  | Active 1 Day | |
|  | Mushrooms | 25.8°C |
| | F4:B8:5E:F2:4E:0A | |
|  | Active 49 Seconds | 52.1%RH |

SELECTING A POD

If you wish to select a Pod to view its current logged data, simply tap on the row of the Pod of your choice. Upon selecting a Pod, Verigo's app will attempt to establish a connection with the Pod if it is within range.





POD STATUS


The Pod Status screen displays vital information about your Pod. Starting at the top of the user interface, there are three key features that allows you to:


- **Ring** Pod to generate a short sound to easily locate your Pod.
- **Stop** Pod to end the current monitoring session and synchronize all logged data.
- **Share** Pod's Data in CSV or PDF format. Or simply share a tracking link by email and other communication apps.

Upon connecting to a Pod, Verigo's app will automatically retrieve all stored data. If an internet connection is present data will be synchronized automatically.

On the Pod Status screen, the following information is displayed:

- Model of your Pod
- Name of your Pod
- MAC address
- Battery level
- When was the Pod started (date and time)
- When the Pod was last synchronized to Verigo's Cloud.
- Real-time temperature, humidity, and Product Life measurements (Humidity only available on PA0 model, Product Life only available on PH0 model).
- Reports of alarm conditions.







POD GRAPH

To view a graph of your Pod's logged data, select the graph button after establishing a connection to a Pod. This feature allows you to interact with your Pod's data.

The first graph shows the temperature logged and recorded for the duration of this monitoring session. If available, the second graph shows the relative humidity that your Pod logged.

POD GRAPH: KEY FEATURES

The plotted graph is fully interactive. To view a specific part of the graph you can pan and zoom-in or out by pinching or expanding your fingers outwards in a similar manner to viewing pictures or maps in other applications.




POD GRAPH: KEY FEATURES CONTINUED

If you wish to view a specific point on the graph, simply tap and hold on the part of the graph for a second to trace the recorded data. This will display the date of its recording, time, and the exact data value of that point (relative humidity is only available on PA0 model).

For mobile devices with small screens there is a unique feature to help you analyze data with ease. Simply tap your finger over the graph to view the recorded data in full screen. This action will rotate and lock the plotted graph in a vertical position for a higher resolution of data.

ANALYSIS TAB

On iOS version of the app you may run a quick analysis of your session by selecting start and end date. The Analysis tab is found between [Graph](#) and [Settings](#). the app




Analysis tab is only available on iOS version of the app.

By default, the start and end date are the dates of the first and last data point that were logged respectively. You may choose a different start and end date to analyze different time periods within your logged session.

A temperature and humidity (*if applicable*) report will automatically be generated upon selecting a start and end date. The report includes;


- Total amount of points that were selected.
- Maximum, minimum, and average readings.
- Time over and under the thresholds. This is the cumulative time that the session spent under or above the configured max/min threshold.
- Longest high and low excursion.
- MKT, or mean kinetic temperature.



POD SETTINGS

You can also view the settings that are currently programmed for this session of data logging by tapping on the [Settings](#) button. These settings cannot be changed while the Pod is active.


In order to change settings, the Pod must be stopped and then configured for future session(s).




STARTING A POD

To start a logging session there are three options that you can choose from. You may;


Configure + Activate Now, here you can configure settings to your Pod and activate it immediately.



Preconfigure Settings for future use, if you choose this option you may write settings to your logger to later activate by pressing and holding the multi-use button on your Pod for 5 seconds. You may also place your Pod in standby mode where the Pod can be activated wirelessly later using the Activate Nearby Device tab.




Activate Nearby Device with preconfigured settings, here you can view the settings that are configured to your Pod and activate any nearby inactive Pods. You may wirelessly activate Pods that are configured for remote start activation and/or simply press the multi-use button on the Pod and select the from the list to view the configured settings and activate it.



CONFIGURING A POD

Setup how the Pod will collect data and alert for each session.

To make changes, simply tap the setting you want to customize, and a number scroll, or your mobile keyboard will appear. There are four subcategories that are fully customizable:



SESSION NAME

Set a custom name for your Pod or scan barcode to identify each individual Pod session

- **Custom Name** allows you to enter a custom name of your preference (20 characters maximum)
- **Scan Barcode** allows you to scan any barcode using your mobile device's camera, which will then appear as the Pod name.



LOGGING DETAILS

Set logging parameters for your logging session. This is where you specify how often your Pod takes a sample of the current environment.

Logging Interval; allows you to set the time interval at which the Pod will record data.

Estimated Duration; displays the amount of time before the data log will be full (40,000 points).


Logging Delay: set a delay for data recording after the Pod has been initiated. For example, the delay time it takes for loading the product into a shipping container.

ALERT SETTINGS

Set alert thresholds for your Pod. If the Pod detects conditions that exceed the current threshold(s) for a specified time an alert message will be displayed upon connecting to your Pod on **Pod Status** and **Nearby** Pod cell will be highlighted in red. Alert setting options include:

Alert After; allows the user to set the accumulated time period that a sensor reading must exceed a threshold before an alert is triggered. The acceptable accumulated time is independently set for each threshold.

Low and High Temperature and Humidity limits. When exceeded, the Pod begins counting down the excursion time to raise an alert after the designated Alert After time.



ADVANCED SETTINGS

Setup advanced settings to get extra settings for even more customization.

Quality Analysis allows you to choose a default or custom Product Life Model that track the remaining life of your product. (For Pod Quality Only, if you wish to learn more about Pod Quality visit farmtoforkfresh.com)

Initial Product Life allows you to enter the remaining life of your product.


Low Product Life Alarm Limit will alert you to when your product drops below your entered remaining life value.

High Resolution; enable to record every small fluctuation, when temperature changes more than 0.5 degree Celsius or humidity changes more than 3%.

Warning: High Resolution logging creates large files that may take longer to download. Only use this option if you need extremely detailed temperature or humidity records.

Remote Start; enabling remote start places your device in standby mode, which will allow you to start your Pod remotely with the app at a future time without physical access or touch the button on the device.

Note: While in standby mode, the device will consume the battery life at the same rate as active mode.



The **Remote Start** option is located inside the “Preconfigure Settings” tab.

SELECTING YOUR POD

Choose a Pod that you would like to start logging data via the following steps:


1. Press the multi-use button on your Pod.
2. Select the inactive Pod from the list.




CONFIRM SETTINGS AND ACTIVATE

This is the last step before starting a Pod. On this page you can confirm that the information and parameters set are correct.


If you wish to start the selected Pod, scroll to the bottom of the settings and tap the “**Activate Now**” button to program the profile you have created. After synchronizing with the Verigo server, you will receive a message stating that the Pod has been successfully initiated and synchronized.



Tap “**Activate Now**”



App will write settings to your Pod.




App notifies that the configuration is complete.

STOP LOGGING SESSION STOP POD

To stop a Pod's current monitoring session and synchronize all data, select the menu option labelled Stop Pod.

Choose a Pod that you would like to stop logging data by doing the following steps:


1. Press the multi-use button on your Pod.
2. Select the active Pod from the list.



After selecting a highlighted Pod, Verigo's app will compile a summary of the Pod readings and settings from the current session. This summary includes:

- Session Name
- Date when it was started.
- Temperature, humidity, and product life summary (when applicable)
- Logging details: logging interval, high resolution logging, and activation method.
- Alarm settings that were set for this session.
- Pod's technical details.

To stop your Pod's current session, simply tap the stop button. Your Pod will synchronize its data to Verigo's Cloud through your mobile device's Internet connection. After the synchronization is done your Pod will no longer be active.




STOP POD: SHARING SESSION DATA

After stopping the Pod, you will have the option to share the data collected via Verigo's share function. The **Share** button is located on the top right of the screen on your mobile device.

This data can only be shared once your Pod has been stopped.

- Share Tracking Link to send a web URL of the records to an email recipient
- Share PDF to generate, download, and send a comprehensive PDF report of the monitoring session.
- Share CSV to generate, download and send a Microsoft Excel® compatible raw data file.



Press the “**Stop**” button.

Wait for your session to sync.

A “**Share**” button will appear after the sync.


Select a sharing option.

You may also share your active session via the **Pod Status** tab. See the Pod Status section for more information.

USER SETTINGS

Users can modify their account settings via the **Settings** tab. There are five subcategories under User Settings, including:

1. **User Details:** displays account username, email, and mobile phone. These settings cannot be modified from within the mobile app.
2. **Personal Preferences:** toggle switch for Celsius and Fahrenheit temperature units to be displayed and time zone setting according to user's preference.
3. **Notifications:** defines how the user prefers to be notified in case an alert message is created.
4. **App Settings;** includes advanced settings that allows the app to collect real-time data from nearby devices and offline mode options.
5. **App Details:** displays the current version of the app.



The **Logout** button is located inside “User Settings”

REAL TIME PING

When Real-Time Ping is active the app collects small bits of data from the devices on its surrounding. A “Ping” is collected from all the nearby Pods and sent to the cloud based on the selected sync-interval, allowing you to automatically receive alerts from your Pod as they are detected. The app will only collect “Pings” from the surrounding devices when the app is opened on your mobile device. The app will NOT collect while the app is running on the background.

To enable **Real-Time Sync** on your mobile device;

1. Go to Settings tab
2. Toggle On the option called **Real-Time Sync**.
3. Enter a sync interval of your choice. The smaller the interval the more frequent your device will send Pings to the web.
4. Make sure to tap Save to apply the new setting.

All “Pings” will be plotted on the graph and it will also be displayed on your session Event log.

Make sure that you have email and/or text message alerts enabled in order to receive notifications. This will allow you to receive alert notifications about your session in real time.




OFFLINE MODE

Offline Mode allows you to collect event and log data without an Internet connection. The collected data will be sent to the server once Offline Mode is turned off.

You may choose between **Manual** and **Auto-Detect**.

Manual: You can manually place the app in Offline Mode. This will store all data logs and events locally until you manually go back online.



You can manually switch between **on** and **off** to into Offline Mode.



Auto-Detect: The app will automatically detect when an Internet connection is not available and enable Offline Mode.

When Auto-Detect is active the app will automatically prompt you to go online when Internet connectivity is detected.

OFFLINE MODE TAB

When Offline Mode is active the app displays an interactive banner. Tapping this banner opens the Offline Mode tab.

The Offline Mode tab contains a ledger of all events and data logs that were collected while you were offline.




Tap the banner on the bottom of the screen to open the Offline Mode tab.




OFFLINE MODE TAB CONTINUED

To synchronize your offline events and data logs you will need to have internet connectivity.


If you manually set the app to go in to Offline Mode, you will have to disable Offline Mode from **Settings** tab, or tap the lightning bolt icon inside the **Offline mode** tab.



Tap the lightning bolt icon on Offline mode tab.



App prompts you to go online.
Tap "yes" to go online.




App begins to sync stored events and sessions.

If Offline Mode is set to **Auto-Detect**, the app will automatically detect Internet connectivity and a pop-up message will ask if you would like to remain in Offline Mode or reestablish online functionality and sync your offline data.

AUTOMATIC MODE



On Android* version 1.10 and above you can automatically start, sync, and stop your Pods. The app will automatically look for nearby devices to connect and perform the desired function. Look for the Automatic Mode symbol on the [Start](#), [Nearby](#), and [Stop](#) tab.



*Automatic mode feature is **not** available on iOS.

AUTOMATIC START

Automatic Start feature is found inside the **Activate Nearby Device** section of the Start tab. This feature will only work for devices that were setup with **Remote Start**. See page 14 for more information on how to setup your devices for **Remote Start**.



Automatic Start is found on the Start tab in the **Activate Nearby Device**


Automatic mode is found on **Start**, **Nearby**, and **Stop** tab.




AUTOMATIC START CONTINUED

To automatically start a batch of Pods, make sure all Pods are inactive and also all Pods were previously configured for Remote Start.


1. Go to Automatic Start.
2. Press the Start button located on the top right of the navigation bar.
3. Choose a Scan Range that the app will scan for devices. Short is 0-2ft (.6 meters). Long is the maximum range possible.
4. Press the Start icon. The app will begin scanning for nearby Pods. If a Pod is found and meets the requirements, the app will place the Pod on the "In Queue" list to be started.




Press Start.



Select your preferred settings.



App scans for nearby Pods.




App places nearby Pods in queue to start.

Troubleshoot: If your Pod is not found while scanning, verify that the Pod is inactive and that it is configured for Remote Start.

AUTOMATIC SYNC

You may use the app as a gateway device to automatically synchronize your sessions to Verigo's Cloud. **Automatic Sync** feature is located on the **Nearby** tab. To automatically sync your Pods to the Cloud, follow the instructions below.

1. Go to the Automatic Sync tab.
2. Press the Start button.
3. Enter your preferred settings on the settings dialogue.
4. Press "Start" button. The app will begin to scan nearby Pods that are active.



AUTOMATIC STOP

Similar to Automatic Start and Sync, you may also configure the app to automatically stop your sessions via the **Automatic Stop** window found inside the **Stop** tab.

To automatically stop your logging sessions, follow the instructions below.

1. Go to Automatic Stop tab.
2. Press the Start button.
3. Enter your preferred settings on the settings dialogue.
4. Press "Start" button. The app will begin to scan and attempt to stop activate sessions.

Tap the **Stopped** section to view sessions that were successfully stopped.


Download progress is shown inside the session cell. Large logs can take up to a minute to download.

| Session Name | MAC Address | Status | Additional Info |
|--------------|-------------------|-------------------|-------------------|
| AUTOS3 | 7C:01:0A:6F:61:21 | Downloading - 32% | |
| AUTOS2 | 84:EB:18:02:D5:21 | In Queue | New device found. |
| FULL LOG RH | F4:B8:5E:F2:4E:21 | In Queue | New device found. |
| PODQUALITY | 7C:01:0A:6F:65:63 | In Queue | New device found. |
| AUTOS1 | 88:C2:55:AF:96:0E | In Queue | New device found. |


USING VERIGO CLOUD

VIEW SYNCHRONIZED SESSIONS

The cloud is where your sessions are stored. To access Verigo's Cloud simply tap on the “Cloud” tab on Verigo's app or you may open a link on your preferred web browser to cloud.verigo.io.



OR



Cloud tab on a mobile device.

Verigo's cloud via your web browser




Make sure that you have the latest version available of your preferred web browser. We recommend Google Chrome or Firefox for best viewing experience.

SESSION MENU

Upon entering the cloud, you are directed to the [Sessions](#) page. On this page there are several tools to help you find and access a session that has been synchronized and to your Verigo's account.

Located on the left side of the screen you will find the main menu.



Search
Search for Session name, or MAC of the session.

Start and End date
defines the lower and upper bounds to search for the most recent sync event.

Filter
You may narrow your search by adding filters for statuses (ex. Active sessions) and/or conditions (ex. Alerted).

Expand / Collapse
Click the three dots to minimize or maximize the main menu.

Battery Level
Select to see different sessions based on their battery level.
Low: 15-30%
Critical: <15%

View Selection
Default view shows all Pods excluding your archived session(s).
All Sessions shows all sessions including archived session(s).
Archived shows only the session(s) placed in Archive.

SESSIONS LIST


In the center of the page you will find a list of all sessions that were synced to your account.

Selector

You can select multiple sessions and add them to your Archive

Pagination

Select the number of sessions that you wish to view per page or navigate to a different session page



The screenshot shows a 'Sessions list' table with columns: Name / MAC Address, Last Reading, Alerts, Activity, Battery Level, and Archive. It lists five sessions: 'Full Log RH' (Log full, Active 92 days), 'PE' (25.80 °C, Active 22 hrs), 'Wrets' (25.00 °C, Completed in 52 mins), 'Proto56' (25.00 °C, Completed in 11 mins), and 'Hello1' (25.30 °C, Completed in 23 hrs). Annotations point to the 'Archive' button in the top right, the 'Archive' button in the 'Full Log RH' row, and the pagination controls at the bottom.

| Name / MAC Address | Last Reading | Alerts | Activity | Battery Level | Archive |
|----------------------------------|--------------|-----------|---|---------------|---------|
| Full Log RH F4:B8:5E:F2:4E:21 | Log full | | Active 92 days Last synced Mar 14, 2019 15:08:16 | 86% | |
| PE 88:C2:55:AF:96:0E | 25.80 °C | No alerts | Active 22 hrs Last synced Mar 14, 2019 15:28:19 | 100% | |
| Wrets 7C:01:0A:6F:65:63 | 25.00 °C | | Completed in 52 mins Last synced Mar 14, 2019 15:04:07 | 100% | |
| Proto56 88:C2:55:AF:96:0E | 25.00 °C | No alerts | Completed in 11 mins Last synced Mar 14, 2019 15:03:54 | 100% | |
| Hello1 84:EB:18:02:D5:21 | 25.30 °C | | Completed in 23 hrs Last synced Mar 14, 2019 15:03:42 | 100% | |

Sessions per page: 10 | 1 - 10 of 11 | < < 12 > >


Archive/Unarchive

Click the archive button to send the session to your archive.

You may also archive each session individually by clicking the archive button on the session cell.

Sessions list is arranged by the latest date that a Pod was synchronized with Verigo servers.

You may sort the session list by using the sorting tool located above the sessions list by *most recent activity*, *last synced*, *session name*, *time active*, and *latest temperature reading*. Clicking the descending and ascending button changes the order of the list accordingly.



Sort function is located above the Sessions list.

Note: If believe that you are missing a session or cannot find it on this page, verify your filter settings from the left menu.



SESSIONS CELL

Each session on the Sessions list is organized by the following format;

Session name

This is the name assigned to your logging session.

Last reading

Last temperature and humidity reading from your device.

Status

Current session status (ex. Active or Completed).

Battery indicator

Battery indicator based on the last time the session was synced.

The screenshot shows a session card for 'Wrets' with the following details: a checkbox icon, the session name 'Wrets', the MAC address '7C:01:0A:6F:65:63', a temperature reading of '25.00 °C', a humidity icon, the status 'Completed in 52 mins' with a sub-note 'Last synced Mar 14, 2019 15:04:07', a battery icon at '100%', and a sync icon. Callouts point to each of these elements with descriptive text.


| Session name | Last reading | Status | Battery indicator |
|----------------------------|--------------|---|-------------------|
| Wrets 7C:01:0A:6F:65:63 | 25.00 °C | Completed in 52 mins Last synced Mar 14, 2019 15:04:07 | 100% |

MAC address
Device individual identifier.

Alert(s) detected
Here you will be able to view a quick glance if your session is alerted.

Last activity
Date and time stamp of the last time the session was synced.

If you wish to view detailed information about a session, click the [session name](#) to go to session details.



Click the session name to view more details.




SESSION DETAILS

By selecting a Pod from the search screen, you access its stored Cloud data. Here you view its sensor and event history.

The Pod's profile shows a basic overview of the session which includes:

- Type of Pod (*ex. Temperature, Humidity, Probe...*)
- Session name
- Date when the Pod was started
- Date when the Pod was stopped
- Alerts (if there are any to be displayed)




| Session Details | | |
|---|-------------------------------------|---|
| DEVICE | SETTINGS | TIMES |
| Session Name shipment 2 | Logging Interval 1 min | Last Synced Time Jan 19, 2018 12:47:14 |
| Device ID (MAC) F4:B8:5E:F2:4E:0A | High Resolution Logging Disabled | Activation Time Jan 18, 2018 14:14:54 |
| Firmware Version 1.9.29 | Raise Alert After 1 min | Logging Start Time Jan 18, 2018 14:15:53 |
| Calibration Date ----- | Start Logging After 1 min | Logging Stop Time Jan 19, 2018 12:46:55 |
| Humidity Coefficients [40, 254, 77, 215, 29, 23] | Activation Method Mobile App | Deactivation Time Jan 19, 2018 12:47:14 |
| Temperature Coefficients [112, 0, 3, 4] | | |
| Battery Level 100% | | |

If you wish to view a more detailed description about the Pod and its parameters click on “[More Details](#)”. This shows a detailed description of the Pod and the parameters set for this logging session.

SENSOR HISTORY


Sensor history of the Pod displays a graph plotted with the logged temperature, humidity, and product life data (if available) on the Y-axis and date and time on the X-axis.





You can interact with the slide bars underneath the graph to zoom in or out to analyze the data with more precision.

Above the graph you will find a few useful tools to help you analyze the session data:

Sensor History

 **Date Range**

 **Sensor Data**

 **Thresholds**

Date range
Select a specific point in time and crop the graph according to your time selection.

Sensor data
You may toggle sensors on and off. This will cause them to show and hide from the graph below.

Thresholds
Allows you to enable and disable threshold limits for temperature, humidity, and product life when available.

DOWNLOAD SESSION REPORT

You may download your session report in your preferred format. To download the report, click the button called Download, which is found below the graph.

+ DOWNLOAD REPORT

Clicking the Download button opens the download options.

Report format
Choose the type of format; PDF or comma-separated-values (CSV).

Display Options
Choose what data will display on your report. Customize to only include desired data.

Report type
If a CSV, choose between Data Log or Event Log.
Datalog is actual points recorded by your sensor.
Event log is the interaction log of events. (Ex. Synced on X date, activated on X date)

Real-time pings
You may choose to include Real-Time Pings with your log. These are small bits of data captured while the app is idle on the Nearby Pod screen.

DOWNLOAD REPORT

REPORT FORMAT
☐ PDF
☒ CSV

REPORT TYPE
☒ Data Log
☐ Event Log

DISPLAY OPTIONS
☒ Show Entire Session
☐ Use Selected Graph Settings

INCLUDE REAL-TIME PINGS
☒ Yes
☐ No

Download

Click the **Download** button when you are ready to download.

Note: PDF reports can take up to 90 seconds to download.



TEMPERATURE

| | | | | | | |
|-----------------------------|------------------------------|-----------------------|-----------------------|-----------------------|-----------------|---------------------------|
| Low alarm limit 20.00 °C | High alarm limit 25.00 °C | Min Value 16.91 °C | Avg Value 19.74 °C | Max Value 24.52 °C | MKT 20.13 °C | Total data points 8277 |
|-----------------------------|------------------------------|-----------------------|-----------------------|-----------------------|-----------------|---------------------------|

HUMIDITY


| | | | | | |
|-------------------------------|--------------------------------|-------------------------|-------------------------|-------------------------|---------------------------|
| Low alarm limit 30.00 % RH | High alarm limit 65.00 % RH | Min Value 14.47 % RH | Avg Value 21.75 % RH | Max Value 45.14 % RH | Total data points 8277 |
|-------------------------------|--------------------------------|-------------------------|-------------------------|-------------------------|---------------------------|

The below graph provides an overview summary of the sensor data for this session which includes;

- Low and high alarm limits
- Minimum, average, and maximum values recorded
- Total number of data points
- MKT, Mean Kinetic Temperature

EVENT HISTORY

Event history compiles a map that shows where people have accessed a Pod based on their GPS data. Event history also logs a timestamp, type of interaction, environmental conditions and the identity of the user that interacted with the Pod.



Event list is organized chronologically. Events can be searched by users and actions taken.

The map is fully interactive and can be panned and zoomed in or out.



Verigo
Truth in Transit

| www.verigo.io |

352.363.5070 |


info@verigo.io

ADMINISTRATOR

On Verigo's Cloud **Admin** tab it is simple to manage user accounts. The administrator home page allows you to search for users with filters by name, email, and roles assigned.

As an administrator you can:

- Add a new user by selecting the Add User link. Fill in the credentials to create a user and select Save to add the new account.
- Delete users by clicking the Delete button after selecting a user.
- Edit user role by selecting that user's name. This action will open their account profile that you have previously created.
- Deactivate users by opening their profiles and selecting "Deactivate".
- Require users to change their password.



As an admin you may add and remove users from your company account.

CREATING AND EDITING CUSTOM PRODUCT LIFE PROFILES

To create or edit your own Product Life Profiles, click on the Admin tab in the upper right of the Verigo Cloud. Two tabs will appear in the upper left, "Users" and "Quality Analysis". Click the Quality Analysis tab to create or edit your profiles.

1. If you wish to create a new profile, simply click on the Create a New Profile button. If you wish to edit a profile, click on View and Modify Profile.
2. A section will appear that allows you to create/update a profile name and description. When finished click continue.
3. A new section will appear that allows you to enter the optimal temperature for your product as well as the number of days the product will last at this temperature. When finished click continue.
4. A new section will appear that gives you the ability to add more data points at different temperatures to increase the accuracy of your model. To add more than one point, click the Add more points button. Once a point has been added, it will instantly be displayed on the graph to the right. To remove data points, click the red X next to the corresponding row of data. When finished click continue.
5. A new section will appear that allows you to save or delete your profile. Once saved you can now access and choose to use your new profile when setting up a Pod Quality.

SETTINGS

Users can modify their profiles and preferences on Verigo's Cloud Settings tab. There are three subcategories under **Settings** that are fully customizable:

Account: edit name, contact email, and add a phone number to receive alerts

Notification; turn on or off notification alerts via email or SMS (text) messages.

Preferences; change temperature units (Fahrenheit or Celsius), preferred time zones, and language preference.

Verigo

Search Admin Settings birdsnpies

Account Notifications Preferences

Profile

Username birdsnpies

Password [Change](#)

First name Ian

Last name Guisard

Contact

Email iguisard@verigo.io

Mobile number 123-345-7890 optional

Country Dialing Code United States (+1) optional

Save

Make sure to save your settings after making changes to your account.
Click the "**Save**" button to store your settings.



PC TOOL

GETTING STARTED

The Verigo PC Tool is a PC software tool designed for computers running Windows 7 and later, with internet access, and which have the specified USB BLE dongle available from Verigo.

This tool is designed to allow distributors, partners, and customers of Verigo to quickly and easily configure or reconfigure the settings and options of a large quantity of Inactive Verigo devices before they are used for a monitoring application.

SYSTEM REQUIREMENTS

In order to use the PC, you must meet the minimum system requirements.

Core i3 2.4 Ghz

4 GByte RAM

USB Type A Port


Windows 7/8/10 32 or 64-bit



INSTALLATION


To install the configuration tool, follow the steps below.

1. Download the attached ZIP file
2. Extract all the files to a folder on your PC.
 - a) Click on the Extract Button, then Extract All




"Extract" option is located on the top of the screen.


3. Open the folder where you extracted the files and double-click the "**install.bat**" file.
 - a) Later versions of the Windows operating system will give you warning messages, dismiss and allow these steps to proceed.
 - b) We recommend you temporarily disable your antivirus program before installing the driver as some antivirus programs raise a false alarm, dismiss and allow these steps to proceed.



4. Follow the steps on-screen prompts to install the necessary Driver.



Follow the steps on the installation wizard.





Click the "Finish" button to close the installation wizard.



PREREQUISITE



Before you begin, be sure that the USB Bluetooth Low Energy dongle is plugged into your computer. If you need an extra USB dongle, please contact your Verigo representative.



Insert the USB Bluetooth Low Energy dongle into the USB socket on your PC.

FIRST RUN

After a successful installation, return to the original folder that you created, and double-click **"batch_conf.exe"**. If you are using Windows 8 or 10 you will receive a warning the first time you open this tool, choose to allow the program to open.



Double Click on **"batch_conf.exe"**

If this is your first time opening the tool Windows might give you a warning. Click the **"Run anyway"** button to proceed.

CONFIGURING DEVICE SETTINGS

LOGIN


The first screen that you see is the login screen. You may use the same account credentials for your company to log in. If you do not have an account, go to www.cloud.verigo.io to create an account.

Enter your username on the first box.

Enter your password on the second box.


After you enter your account credentials click the **"LOGIN"** button to sign-in and access the tool.

If you would like an existing account to be setup for use with the configuration tool, please send an email including this request and the username to support@verigo.io.



CONFIGURING SETTINGS TO POD

Input the desired configurations from the options listed in the **"Primary Settings"** and **"Advanced Settings"** panes. If a particular setting is not selected using the checkbox to the left of that setting, the tool will not edit the value of that setting when programming the device.



Primary Settings



Advanced Settings



Verigo
True In Transit

| www.verigo.io

| 352.363.5070

| info@verigo.io

Primary Settings

Session Name

☒ Custom Name + Index
(15 char max) +

☐ S/N + Custom Name
(13 char max)

☐ Unique Name per device

Activation Mode

☒ Configure Activation Mode

☒ Activate Immediately

☐ Remote Start (Standby Mode)

☒ Enable ☐ Disable

* The pod will be activated as soon as it is configured.

Logging Options

☒ Logging Interval minutes

☒ Logging Delay minutes

☒ High Resolution Logging

☒ Enable ☐ Disable

Alert Settings

Temperature

☒ Low Alarm Limit °C ☐ No Limit

☒ High Alarm Limit °C ☐

Humidity

☒ Low Alarm Limit % RH ☐

☒ High Alarm Limit % RH ☐

☒ Alert After minutes ☐

Naming Options

Activation Mode

Logging Settings

Alert Settings

PRIMARY SETTINGS

In the primary settings section you will find the most basic settings for your logging session as well as the activation method. These settings will be used to configure and activate your batch of Pods.

- **Session name**; allows you to enter a custom name for each session or standard for all devices.
- **Activation Mode**; defines how the session starts (*immediately, button press, and/or remotely*).
- **Logging Options**; sets when and how frequent the device logs data.
- **Alert Settings**; sets a minimum and maximum, temperature and humidity threshold for your setting.

Advanced Settings

Access Control

☐ Enable "Access Control" ☐ Disable "Access Control"

Enter Email Address:

Company Found:

Primary owner:

Assigned owners:

Quality Analysis

☐ Enable Quality Analysis

Select Shelf Life Profile

☐ Initial Shelf Life days

☐ Low Shelf Life Alarm Limit days

Device Settings

☐ New Calibration Date

Pod Access Control

Quality Analysis

Device Settings

ADVANCED SETTINGS

Advanced settings allow you configure access control, set quality analysis and other settings that are not available via the app.

- **Access Control**; allows you to control block access from unidentified companies and grant access to specific companies to your device.
- **Quality Analysis**; loads a shelf life profile to the logging session. This feature is only available for Pod Quality users.
- **Device Settings**; this section is only available for authorized users.



SCANNING NEARBY PODS

After entering your desired settings and confirming they are correct for the devices to be configured, the “**Lock Settings**” button. The “**Start Scan**” button will only become available after you lock your current settings. If you wish to modify your settings, you must click the “Unlock Settings” button.

To begin configuring devices, click the “**Start Scan**” button.



Press the “**Lock Settings**” button, then press the “**Start Scan**” to begin the process.


Bring the inactive device(s) to be configured to within less than 1 meter (*3 feet*) of the USB BLE dongle, and briefly tap the button on the first device that you would like to configure.



Bring the Pod close to the USB dongle and Press the button on Pod.

SCANNING NEARBY PODS: CONTINUED

After the button is tapped, you should hear two beeps from the device as the tool connects to and configures the Pod. Within 3-10 seconds the configuration will be complete, and an entry will appear in the table showing the details of the device and its configuration, with a “checkmark” symbol to the left of the table entry indicating “Success”.



| | MAC | Serial # | Model | Session Name | Log Int. | Log Delay | Hi-Res. | Start Mode | Low T Lmt. | High T Lmt. | Low RH Lmt. | High RH Lmt. | Comp. ID(s) | S |
|---|----------------|----------|-------|--------------|----------|-----------|---------|------------|------------|-------------|-------------|--------------|-------------|---|
| ✓ | 84EB 1802 E25F | (09) | (PA2) | demo1 | 1 mins | 20 mins | ON | Normal | 10.0 C | 25.0 C | 20.0 % RH | 65.0 % RH | None | |

Check mark indicates that the configuration was **completed**.

Table entry shows the settings that were configured to the Pod.

While the scanner is active you may configure multiple Pods by following the step above.

Please note: Be sure to keep the device within 3 feet of the Tool for the entire time that it is being configured.

The tool will not configure devices that are in the active monitoring state. You must stop any current monitoring session using the Verigo’s app before attempting to configure using the Windows batch configuration tool.

If the tool encounters an error while attempting to configure a particular device, a popup error dialog will appear with details, and the entry in the table will show a “warning” symbol to the left of the corresponding table entry.




EXPORTING WORK LOG

If desired, you may save a CSV log containing records of all the scanned devices.

| UNLOCK SETTINGS | | | STOP SCAN | | | | | | | | | | EXPORT CSV | | | |
|-----------------|----------------|-----------|-----------|--------------|----------|-----------|---------|------------|------------|-------------|-------------|--------------|-------------|--------------|------------|-----------|
| | MAC | Serial # | Model | Session Name | Log Int. | Log Delay | Hi-Res. | Start Mode | Low T Lmt. | High T Lmt. | Low RH Lmt. | High RH Lmt. | Comp. ID(s) | S.L. Profile | Init. S.L. | S.L. Lmt. |
| ✓ | 84EB 1802 E25F | (09) | (PA2) | demo3 | 1 mins | 5 mins | ON | Normal | -10.0 C | 25.0 C | 20.0 % RH | 55.0 % RH | None | | | |
| ✓ | F4B8 5EF2 4E77 | () | (PA2) | demo2 | 1 mins | 5 mins | ON | Normal | -10.0 C | 25.0 C | 20.0 % RH | 55.0 % RH | None | | | |
| ✓ | 88C2 55AF 960E | (011429) | (PE0) | demo1 | 1 mins | 5 mins | ON | Normal | -10.0 C | 25.0 C | | | None | | | |

Click the Stop **Scan button** then select the **Export CSV** option.

1. When all devices have been configured, click **Stop Scan**
2. Then click the option **Export CSV**.
3. Select a folder that you wish to save the CSV
4. Click the **Save** button.




Click the Stop **Scan button** then select the **Export CSV** option.



SYNC AND STOP


OVERVIEW

The PC tool can be used as a gateway to automatically sync and stop sessions. To access this feature simply select the Sync/Stop option located on the top navigation bar of the tool.




SCAN MODE


Scan mode is found in the settings option of the Sync/Stop tab. You may choose when and how the loggers are scanned. There are two different modes **Manual Sync** (default setting) and **Automatic Sync**.



Manual Sync; when this mode is selected you are required to press the button on the logger to trigger a sync.



Automatic Sync; any logger within the scan range will be automatically synchronized.




SCAN RANGE

Scan range allows you, to configure the distance of how far you want to tool to scan. This is especially helpful in operations where you would want to limit the number of Pods that you want to scan.

There are two ranges that you may choose from, short and long range*. Short range is less than 1 meter. Long range is the maximum range possible that the sensor can detect.


*It is worth noting that barriers such as walls, doors, and other objects can drastically affect the range that the tool can reach.




STOP OPTIONS

Besides the ability to sync you can also configure the tool to stop and end the logging session after syncing the data-log to the cloud.

To enable stop after sync, select the option to “**Stop after successful sync**”. When this option is selected the tool will stop the logger after a successful sync. Sessions that are not successfully synced will **not** be stopped.



In “**Stop Options**” section you can also enable or disable the remote activation feature. Enabling “**Standby Mode**” places your logger in standby state, which will allow you to start your logger remotely with the app a future time without having to physically access or touch the button on the logger. The logger can be activated at any time in the future using the “**Activate Nearby Device**”* tab.



Select “**Activate Nearby Device**” the Android app to activate loggers in standby mode.

*“Activate Now” tab is currently only available on the Android version of the app.

SCANNING NEARBY LOGGERS

The Sync/Stop feature acts in a similar fashion to the Configure Device(s) tab of the tool. First you must configure your desired settings (Scan mode, range, and stop options). Then you must lock your settings. After clicking the “[Lock Settings](#)” button, you will be able to start the scan by selecting the “[Start Scan](#)” button.

Configure Device(s) Sync/Stop Battery % Reset

Settings

Scan Mode

Select a scan mode (required)

☒ Manual Sync (Button Press)

☐ Automatic Sync

This mode requires the user to press the button on the logger to trigger a sync.

Scan Range

Select a range to scan

☒ Long (max range)

☐ Short (<1 meter)

Stop Options

☒ Stop after successful sync

☒ Configure Standby Mode

☐ Disable Standby Mode (default)

☒ Enable Standby mode

* Loggers will be deactivated after successful sync.

Enables the Remote Start (Standby Mode) feature, which allows you to remotely activate your logger using the mobile app.

Inactive

First choose your desired scan and stop options.

LOCK SETTINGS

START SCAN

Lock your settings in lock by clicking the “[Lock Settings](#)” button.

UNLOCK SETTINGS

START SCAN

Click the “[Start Scan](#)” button to initiate the scan.

| Synced | Stopped | Serial # | Model | MAC | Session Name | Start Date | Stop Date | Start Method | Alert Status | Low Temp | High Temp |
|--------|---------|----------|-------|--------------|--------------|------------|-----------|--------------|--------------|----------|-----------|
| False | False | None | None | 7C010A6F6121 | Woha | None | None | None | None | None | None |

The list is populated with loggers that are found.

| Synced | Stopped | Serial # | Model | MAC | Session Name | Start Date | Stop Date | Start Method | Alert Status | Low Temp | High Temp |
|--------|---------|----------|-------|--------------|--------------|---------------------------|----------------------------|--------------|--------------|----------|-----------|
| True | True | 95771 | PA2 | 7C010A6F6121 | Woha | 2018-06-13 21:13:12+00:00 | 2018-06-13 21:13:29.687000 | ButtonPress | No Alerts | 27.87 | 27.87 |

After a session is synced the entry on the list is updated with the session information.

